



***INTELLISPEC™ CPE***  
***Series 6 CSLX***  
***Inspection Module***  
***Addendum***

MANUAL PART NUMBER: 86198 REV. 01

HARDWARE MODEL NUMBER(S): 85954

## **Copyright Notice / Contact Us**

© 2024 Pressco Technology Inc. All rights reserved.

No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Pressco Technology Inc.

The contents of this manual are furnished for informational use only, are subject to change without notice, and should not be construed as a commitment by Pressco Technology Inc.

Written and designed at:

Pressco Technology Inc. World Headquarters

29200 Aurora Road

Cleveland, OH USA 44139-1847

TEL +1-440-498-2600

FAX +1-440-498-2615

[www.pressco.com](http://www.pressco.com)

Business Hours: Monday - Friday, 8:00am - 5:00pm Eastern Time

Customer Support:

Request technical support and remote support: [techsupport@pressco.com](mailto:techsupport@pressco.com)

24/ 7 Customer Support (for urgent system help): +1-440-498-2000

e-mail: Schedule a service visit: [dispatch@pressco.com](mailto:dispatch@pressco.com)

Request technical support and remote support: [techsupport@pressco.com](mailto:techsupport@pressco.com)

Customer Service Fax: +1-440-498-4761

## Table of Contents

|  |    |
|--|----|
| Chapter 1 Pressco Introduction .....                     | 5  |
| About This Manual .....                                  | 5  |
| Safety Considerations .....                              | 6  |
| Static Discharge Protection .....                        | 6  |
| Chapter 2 Safety Information .....                       | 7  |
| Health Warning - Photosensitive Epilepsy .....           | 7  |
| Symbols Used With This System .....                      | 8  |
| Arc Welding Warning .....                                | 9  |
| Label Description - Intellispec .....                    | 9  |
| Warning Devices .....                                    | 10 |
| Light Tree .....   | 10 |
| Residual Risk .....                                      | 10 |
| Intended Use .....                                       | 10 |
| Prohibited Use .....                                     | 11 |
| Personal Protective Equipment .....                      | 11 |
| Personnel Safety .....                                   | 11 |
| Lifting Heavy Objects .....                              | 13 |
| Authorized Users .....                                   | 13 |
| Spare Parts Usage .....                                  | 14 |
| Chapter 3 System Specifications .....                    | 15 |
| Environmental Conditions .....                           | 15 |
| Electrical Specifications CPE Series 6 CSLX Module ..... | 15 |
| Sound Pressure Level .....                               | 15 |
| Chapter 4 Installation .....                             | 17 |
| Shipping and Handling .....                              | 17 |
| Recommendations Prior to Installation .....              | 17 |
| Assembly, Location, and Mounting Requirements .....      | 18 |

|  |    |
|--|----|
| Installation .....   | 20 |
| Commissioning .....  | 20 |
| Chapter 5 CPES6 CSLX Inspection Module .....                   | 21 |
| CPES6 CSLX Components .....                                    | 22 |
| Inspection Module Adjustments .....                            | 25 |
| Observe the Part Image .....                                   | 25 |
| Adjust the Camera Position .....                               | 26 |
| Lighting Adjustments .....                                     | 27 |
| Chapter 6 Wiring Diagrams CPE S6 Inspection Module .....       | 28 |
| Wiring Diagram CSLX Top Enclosure Sheet 1 .....                | 29 |
| Wiring Diagram CSLX Top Enclosure Sheet 2 .....                | 30 |
| Wiring Diagram CSLX Main Enclosure Sheet 3 .....               | 31 |
| Wiring Diagram CSLX Main Enclosure Sheet 4 .....               | 32 |
| Wiring Diagram CSLX Main Enclosure Sheet 5 .....               | 33 |
| Wiring Diagram CPES6 CSLX Sheet 6 .....                        | 34 |
| Chapter 7 Maintenance Frequency with Chromapulse Modules ..... | 36 |
| Maintenance for the Inspection Module .....                    | 36 |
| Clean or Replace the CPES6 Fan Filters .....                   | 38 |
| Clean the Optical Surfaces .....                               | 39 |
| Clean the Glass Surfaces .....                                 | 39 |
| Clean the Chromapulse Beam Splitter .....                      | 39 |
| Clean the Plastic Surfaces - general .....                     | 40 |
| Clean the Part Detector without the Reflector .....            | 40 |

# Chapter 1 Pressco Introduction

Welcome!

Congratulations on your purchase of an Intellispec system! The Intellispec is a high-speed machine vision system designed specifically for product and online process monitoring. It is a powerful tool that provides inspection much more reliably than the human eye or sampling methods. The latest PC technology, powerful inspection algorithms, online adjustment capability, and inspection data storage allow the Intellispec to automatically inspect parts with extreme accuracy on high-speed lines.

The Intellispec will help you provide the highest quality of products shipped to your customers.

## About This Manual



*IMPORTANT: Keep this manual for future reference*

This manual provides hardware information for the Intellispec inspection module, including maintenance instructions and wiring diagrams.

We recommend a formal training class either in our classroom facilities in Cleveland, Ohio USA, or on-site at your facility. Please contact Pressco's training department for information about classes. This manual should be used as a reference after you have received training.

Related books include:

- Intellispec Operator's Guide which has Operator-level user instructions, and is a good place to start if you are new to Intellispec
- Intellispec Software Guide which has Administrator-level user instructions
- Intellispec Hardware Guide (multiple options), which describes the vision processor and cabinet

**The following types of alerts may appear in this guide:**



**DANGER!** - Danger messages alert you to specific conditions that can cause serious or fatal personal injury. Danger messages give you important information which must be observed to prevent injury.



**WARNING:** - Warning messages indicate information which must be observed to prevent injury, data loss, or equipment damage.



**CAUTION** - Caution messages indicate important information which must be observed to prevent: loss of data, poor system performance, or equipment damage.

*Note: Notes contain special information that warrants being set off from the body text as shown here.*



**IMPORTANT** - Indicates prerequisites or information that must be observed to complete or understand a concept or task.

**TIP:** Provides helpful hints for completing a task.

---

## Safety Considerations

Observe the following safety warnings when operating the system or working near it:



*WARNING - Potential for projectiles to strike persons and cause injury. Keep clear of reject devices.*



*WARNING - Sensitive electronics and High Voltages may be exposed. Keep Processor Cabinet/ Electrical Control Box door closed.*

---

## Static Discharge Protection




*Caution - Electronic components can be damaged by static electricity discharge.*


Always observe the following precautions before removing, installing or handling any electronic components within the Inspection System:

- Wear an anti-static wristband which is grounded to the Inspection System.
- Stand on an anti-static, grounded floor mat, and lay circuit boards on the mat during any board replacement.
- Keep circuit boards in static shield bags when storing and transporting. Ensure the bag is sealed.

## Chapter 2 Safety Information

This section contains operator safety information that must be read before operating or servicing the system.


 **WARNING** - This product contains no operator serviceable parts. Refer servicing to qualified personnel. To prevent electrical shock do not open cabinet doors whilst power is connected.

 **WARNING** - Do not, under any circumstances, tamper with sealed machine parts or devices. This could result in the removal of protections that might create potentially hazardous conditions.

 **CAUTION** - Possible hazardous optical radiation from LEDs. Do not stare at lamps.

Observe the following safety warnings when operating the system or working near it:

 **WARNING** - Potential for projectiles to strike persons and cause injury. Keep clear of reject devices.

 **WARNING** - Sensitive electronics and High Voltages may be exposed. Keep Processor Cabinet/ Electrical Control Box door closed.

### Health Warning - Photosensitive Epilepsy

 **WARNING: PHOTSENSITIVE EPILEPSY/ SEIZURES**

A small percentage of individuals may experience epileptic symptoms or seizures when exposed to certain patterns or flashing lights. Exposure to the flashing lights in vision inspection systems may also trigger epileptic symptoms or seizures in these individuals. These flashing lights may trigger epileptic symptoms or seizures in persons who have no history of epileptic symptoms or seizures. If you, or anyone in your family has an epileptic condition or has had seizures of any kind, consult your physician before operating this machinery.

IMMEDIATELY DISCONTINUE use and consult your physician if you experience any of the following symptoms while operating this machinery:

- Dizziness
- Altered vision
- Eye or muscle twitches
- Loss of awareness
- Disorientation
- Seizures
- Any involuntary movement or convulsion

**Epileptic symptom or seizure triggers vary from person to person. Some common triggers are:**











- Flashing lights used for vision inspection systems or fire alarms
- Certain video games or TV broadcasts containing rapid flashes or alternating patterns of different colors
- Bright, contrasting patterns such as white bars against a black background
- Flashing white light followed by darkness
- Stimulating images that take up your complete field of vision, such as being very close to a TV screen or computer monitor
- Certain colors, such as red and blue






***If you encounter something that might trigger epileptic symptoms or seizures without warning:***

- Do not close your eyes (this could cause a flicker effect)
- Do not look directly at the flashing lights or trigger source
- Do cover one eye with the palm of your hand immediately
- Do turn away from the flashing lights or trigger source

## Symbols Used With This System

The following symbols are used on or near the Pressco system. Be aware of potential risk hazards.

| Symbol  | Meaning   |
|---|---|
|   | CAUTION: Risk of danger. Refer to accompanying user documentation before use. |
|  | WARNING: Risk of electric shock   |
|  | WARNING: Arc flash and shock hazard   |
|  | WARNING: Risk of electrical shock   |
|  | WARNING: Risk of burns from hot surface                                       |
|  | WARNING: Hand crush hazard  |
|  | On (supply)   |
|  | Off (supply)  |
|  | Alternating current   |
|  | Protective conductor terminal   |


|   |   |
|---|---|
|  | <p>Warning: Arc flash and shock hazard</p>            |
|  | <p>Warning: UPS voltage present when power is off</p> |
|  | <p>Warning: UPS Disconnect</p>                        |
|  | <p>Warning: Electrical interlock</p>                  |
|  | <p>Danger: shock and arc flash explosion hazards</p>  |

## Arc Welding Warning

**⚠ WARNING** - Potential equipment damage can occur if the vision equipment is not fully powered down prior to any arc welding performed on the line where the vision equipment is installed, specifically but not limited to our encoders.

## Label Description - Intellispec

The following illustration shows an example label that you will find on the Intellispec system components.



- 1) Name of component. NOTE: The Chromapulse model is listed on the front panel of the module.
- 2) Voltage range in Volts AC

- 3) Frequency range in Hertz (Hz)
- 4) Maximum rated power in watts (W) with all accessories or plug-in modules connected
- 5) Serial number is listed in this box
- 6) Year of manufacture
- 7) Component certification
- 8) Risk of danger. Refer to accompanying documentation before use.

---

## Warning Devices

The Pressco system has warning devices that indicate system failure or report excessive defects or warnings for your production line. These include an optional light tree, alarms and indicators on screen, and audible warnings (depending on system).

---

### Light Tree

The optional light tree is mounted on a pole in a customer-specified location.



The light tree color segments represent each alarm or system condition. A color segment may appear for more than one alarm condition.

---

### Residual Risk

The Pressco system has been designed to minimize any danger of personal injury. However, the system uses rejection devices to remove defective product from the production stream. Also, the electronics cabinets contain risk of shock if they are opened.

Observe the following safety warnings when operating the system or working near it:



*WARNING - Potential for projectiles to strike persons and cause injury. Keep clear of reject devices.*



*WARNING - Sensitive electronics and High Voltages may be exposed. Keep Processor Cabinet/ Electrical Control Box door closed.*

---


### Intended Use

**Type of Process** - The Pressco system is intended to monitor container and other special manufacturing processes and identify non-conforming product.

**Intended Use** - The Pressco system is designed and constructed for use in an indoor industrial environment, always sheltered from the weather.




**Space Required** - The Pressco system and accompanying sensors must be installed in a place that will enable safe and easy installation, size changeover, user operation, and maintenance procedures.

## Prohibited Use


 **WARNING** - If this instrument is not used as specified, the protection provided by the equipment could be impaired. This instrument must only be used in a normal condition (in which all means of protection are intact).

 **Important** - The Pressco system should NOT be used for any purpose other than specifically indicated in the section titled "*Intended Use*" on the previous page.






The following uses are not intended:

-  Use in an explosive environment
-  Use in a flammable environment
-  Use in a damp, moist, or wet environment, except where specifically indicated

## Personal Protective Equipment

 **Important** - Always follow the safety requirements of your plant in addition to the recommendations below.

We recommend, at minimum, use of the following Personal Protective Equipment (PPE):

|   |                                    |
|---|------------------------------------|
|  | Protective clothing                |
|  | Protective gloves                  |
|  | Protective ear plugs or headphones |
|  | Protective eye wear                |
|  | Protective foot wear               |




## Personnel Safety

The following rules are recommended to ensure the safety of personnel in charge of machine operation and maintenance.







### **During machine operation:**









Only one operator is needed to operate the machine. All others must keep at a safe distance.

|   |  |
|---|--|
|  | <p>Operators must be familiar with all machinery connected to the Pressco equipment and know how to use emergency stop devices.</p> <p>Note: the emergency stop devices may not be connected directly to the Pressco equipment, but it is important to know how to use them.</p> |
|  | <p>Before putting the Pressco system online, the operator must ensure that all safety devices used with all connected machinery are in place and operational.</p> <p>Do not operate with guards removed.</p>   |
|  | <p>The operator must maintain maximum focus on his work and be alert throughout his shift. If this is not the case, immediately inform the shift supervisor.</p>   |

**When carrying out maintenance or repair work:**

|   |  |
|---|--|
|    | <p>Disconnect master switch. For switch locations, refer to the Power Up and Power Down section.</p>   |
|    | <p>Before starting the machine, ensure that no person is close to the machine.</p>   |
|    | <p>If maintenance or repair requires the disconnection or removal of safety or protection systems, this operation must be supervised by authorized personnel who must ensure the prevention of personal injury or damage to the machine. All machine movements must be performed with limited speed and limited movements.</p> |
|  | <p>Maintenance or repair work on electrical components must be carried out exclusively by authorized, trained personnel. When running tests with power connected, you must strictly comply with the rules provided.</p>  |
|  | <p>Personnel working on higher parts of a machine must wear a harness and hook it on to the structure and must always move with extreme caution.</p>   |
|  | <p>Never perform lubrication or maintenance procedures on mechanical parts with the machine running.</p>   |

**For your safety, do not:**

-  Open safety guards during machine operation
-  Perform maintenance and repair while the system is running
-  Lean on the machine
-  Sit on the machine components
-  Use the machine for purposes other than those listed in this manual
-  Modify parts of the machine



Allow unqualified personnel to operate or perform maintenance procedures on the machine

## Lifting Heavy Objects



**CAUTION** - Some components are heavy. Take proper precautions to prevent personal injury or damage to equipment. If you are not capable of lifting the object alone, ask a capable person to help lift the object, or use a mechanical lifting device

The components do not have handles to lift the equipment. Be sure to:

- Lift equipment from the bottom - do not use wires, brackets, nor other protrusions
- Keep fingers away from sensor lenses to keep the equipment clean
- Proceed slowly



**WARNING**- The Pressco cabinets must NOT be lifted by one person. Use a mechanical lifting device, and ask another person to assist you.



Do not twist your body when moving the load. Instead take small steps with your feet turning until you are in the correct position.

### **To safely lift equipment:**

1. Stand close to the load and center yourself over it with your feet shoulder width apart.
2. Tighten your abdominal muscles.
3. Keeping your back straight, bend your knees and squat down to the floor.
4. Get a good grasp on the load with both hands.
5. Keeping the load close to your body, use your leg muscles to stand up lifting the load off the floor. Your back should remain straight throughout lifting, using only the muscles in the legs to lift the load.
6. To place the load in the appropriate spot, bend at the knees using only your leg muscles to lower the load.

## Authorized Users

Trained machine operators, mechanic and electrical maintenance staff, and plant managers are considered authorized users of the Pressco system. These users should carefully read the information contained in this manual. The plant manager must ensure that the safety recommendations included in this manual are observed.



**WARNING** - Allowing workers who are unfamiliar with the production process to operate the Pressco system could result in hazard risk.

If you are unclear about any part of this manual, contact Pressco Technical Support.



**Important** - No worker should ever operate the system outside of his/ her own area of competence and responsibility.

**Proper Operation:** - Only one worker is to operate the system at any given time. The correct position for the operator is in front of the user interface monitor or control enclosure (if applicable).

**Repairs:** - Any repair on the system shall be carried out exclusively by Pressco Technology Inc. service personnel or by other service expressly authorized by Pressco Technology Inc.

---

## Spare Parts Usage

The following restrictions apply to replacing parts:



*WARNING - Using spare parts that are not designed to Pressco's specifications can compromise the safety and effectiveness of the Pressco system.*

- The use of parts that are not within Pressco's design specifications is prohibited. This prohibition applies in particular when the parts involved contain or are connected with safety devices.
- Before resuming production, make sure all safety devices are in working order.

Pressco Technology Inc. shall not be liable in any way if any of the above-described directions are not complied with.

To obtain a spare parts list, contact the Spare Parts department at Pressco: [SpareParts@pressco.com](mailto:SpareParts@pressco.com). Or call +1-440-498-2000 (Monday - Friday 8AM - 5PM Eastern time).

In addition, Pressco's technicians are available to help customers, in their own plant, to solve any problem that might arise during use and maintenance of the system.

## Chapter 3 System Specifications

This instrument has been designed and tested in accordance with Publication EN61010-1 (2010) Safety Requirements for Electrical Equipment for Measurement, Control and Laboratory Use and has been supplied in a safe condition. The instruction documentation contains information and warnings which must be followed by the user to ensure safe operation and to maintain the instrument in a safe condition.

### Environmental Conditions

The Intellispec system is designed to be safe in the following environmental conditions:

*Note: Please consult Pressco Technology Inc. if your environmental conditions are outside of those listed.*

| Condition                     | Specifications   |
|-------------------------------|--|
| Indoor/ outdoor use           | Indoor use only  |
| Altitude                      | Up to 2000 meters  |
| Operating Temperature         | 5 °C to 40 °C  |
| Storage Temperature           | 0 °C to 70 °C  |
| Humidity                      | Maximum relative humidity 80 % for temperatures up to 31 °C decreasing linearly to 50 % relative humidity at 50 °C   |
| Mains supply                  | Voltage fluctuations up to $\pm 10$ % of the nominal voltage   |
| Overvoltage protection rating | Transient overvoltage typically present on MAINS supply<br>NOTE: the normal level of transient overvoltages is impulse withstand (overvoltage) category II of IEC 60364-4-443. |
| Rated pollution degree        | This instrument is designed for use in Installation Category II and Pollution Degree 1 as per EN61010-1 and EN60664 respectively.  |



*Warning - This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.*

### Electrical Specifications CPE Series 6 CSLX Module

**Input voltage:** 100-240VAC

**Power:** 300W max.

### Sound Pressure Level

The horn on the optional light tree has a maximum 105dB level at 1 meter distance in front of the horn. Use proper hearing protection as specified by your plant safety instructions.


## Chapter 3

This page left blank intentionally

## Chapter 4 Installation

This section contains information about installation requirements and preparations that need to be complete before installing the system.

Pressco Technology Inc. recommends that the machine be installed and assembled by Pressco's specialized technicians. This is of vital importance for correct machine operation.


 **WARNING** - Pressco Technology Inc. shall not be liable in case of failures or damage to property and/or personal injury resulting from or connected with assembly if this has been carried out by unauthorized personnel, or is not in compliance with the indications given in this manual.


To carry out production and cleaning/ servicing operations, it is important for the machine to have a minimum amount of space all around and away from walls.

### Shipping and Handling

Pressco Technology Inc. ships unassembled components in packing cases designed to protect the contents during handling and from exposure to weather.

Unless otherwise specified in the contract with the machine order, the Customer shall supply Pressco Technology Inc. with the means and equipment necessary for the unloading, lifting, and handling of machine parts. Pressco Technology Inc. deems it important to have one of their technicians supervise the process of unloading, handling, and lifting the machine. The technician can give useful advice as to the logical sequence in which the components should be unpacked and positioned for ease of assembly.

 **WARNING** - Only qualified personnel must be involved in the operation of unloading, handling, and lifting the machine. Pressco Technology Inc. shall not be liable for damage to components and/or personal injury resulting from the involvement of unauthorized personnel and/or failure to comply with the directions provided in this manual in relation to lifting and transport.

 **Important** - The site supervisor will be responsible for ensuring that all the various mounting phases are carried out safely and in compliance with current regulations.

After the machine is delivered, check for any damage that might have occurred during shipping. In case of damage, contact Pressco Technology Inc.

In handling the machine, always keep it close to the ground.



We recommend using a forklift truck with adequate capacity and forks to suit the weight to be lifted (machine plus packaging).

### Recommendations Prior to Installation

Before the machine is installed, the Pressco installer, together with the Customer (or representative) shall check the following criteria in the environment where the machine is to be installed:

- Work required by contract for the installation of the machine has been carried out
- The plant layout drawing that describes where the machine will be installed is the final drawing agreed to by Pressco Technology Inc.
- The space and height required for installation are actually available
- Only the components included in the installation layout are present in the area where the machine is to be mounted. Ensure no machines or components have been added at a later stage that might hinder mounting or make it more difficult. Should this be the case, immediately contact Pressco's Project Engineering personnel to arrange a suitable solution to the problem.

We recommend the following prior to machine installation:

- Transport the machine in its packaging to the area where it will be installed to minimize possibility of damage
- Carefully remove the packaging material and check components for damage
- Check tightness of mechanical components, as they can loosen during transport
- Prepare the compressed air mains line. Before making final connections, ensure that the pipes are clean and free from any debris.

## Assembly, Location, and Mounting Requirements

### Utilities to be Supplied by Customer

The following utilities are required to operate the Pressco Intellispec system. Before making connection, make sure the utility matches the technical specifications. More than one connection of the utilities may be required depending on the number of modules installed. Refer to specific wiring diagrams.

| Utility                         | Requirements   |
|---------------------------------|--|
| Air supply for rejection device | Pipe size must be such that there will be no pressure decrease during machine operation. Air must be dry and free of oil.  |
| Electrical supply               | Provide one each electrical socket to comply with: <ul style="list-style-type: none"> <li>• User interface electrical specifications (use the specifications that apply to your system)</li> <li>• Integrated tunnel electrical specifications (if applicable)</li> <li>• Cluster box electrical specifications (if applicable)</li> </ul> |
| Internet connection (optional)  | Provide a shielded ethernet cable to use Pressco's remote support through the Internet.  |

### Protective Earthing

This product must be grounded (earthed). If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock.

**⚠ DANGER** - Improper connection of the equipment grounding conductor can result in a risk of electric shock. Check with a qualified electrician or service technician if you are in doubt as to whether the product is properly grounded.

**Cord Connected Equipment**

The product will be equipped with a supply cord having an equipment grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet that is properly installed and grounded in accordance with local codes and ordinances.

Do not modify the plug provided with the product - if it will not fit the outlet, have a proper outlet installed by a qualified electrician.

**Cable Direct**

This product must be connected to a grounded metal, permanent wiring system, or an equipment grounding conductor must be run with the circuit conductors and be connected to the equipment grounding terminal.

**Electrical Connection**


Make sure that the power outlet voltage matches the voltage required by the machine. Refer to the electrical specifications and wiring diagrams for your system.

**⚠ WARNING** - Power Switch is the power disconnect device. Do not position the equipment such that access to the disconnect switch is impaired. If not readily accessible (such as within a rack or mounting out of reach), an additional disconnect device should be installed that can isolate the Live and Neutral lines of the mains power supply, whilst leaving the protective earth intact.


**Reject Valve Pneumatic Diagram**

This diagram shows the reject device connection to the 8-port I/O box. This is for Intellispec systems.

8-PORT I/O BOX  
57006



REJECT VALVE PNEUMATIC DIAGRAM



## Installation

Pressco Technology Inc. recommends that the machine be installed and assembled by Pressco's specialized technicians. This is of vital importance for correct machine operation.



**WARNING** - Pressco Technology Inc. shall not be liable in case of failures or damage to property and/or personal injury resulting from or connected with assembly if this has been carried out by unauthorized personnel, or is not in compliance with the indications given in this manual.

To carry out production and cleaning/ servicing operations, it is important for the machine to have a minimum amount of space all around and away from walls.

## Ventilation

Place the Pressco Intellispec components in a position with adequate ventilation to allow proper air flow through the air filters.

| Component                             | Spacing   |
|---------------------------------------|---|
| User Interface                        | Leave 1 meter [39 inches] clear around machine  |
| Cluster box (not used on all systems) | Leave 100 mm clear in front of the fan and vent |


## Commissioning

Before placing the machine into operation, make sure the following checks are completed:

| Completed   | Yes | No |
|---|-----|----|
| Positioning and leveling of the unit  |     |    |
| Connection of compressed air line to connection points  |     |    |
| Connection of power supply to vision processor cabinet  |     |    |
| Connection of power supply to cluster box (if applicable)   |     |    |
| Connection of power supply to integrated inspection module(s) if applicable   |     |    |
| Proper wiring from user interface cabinet to sensor module(s) and cluster box (if applicable) using the wiring diagrams |     |    |

## Chapter 5 CPES6 CSLX Inspection Module


This view of the module shows a version with a CP1200E array at the bottom. Your module may have a different sized array.



## CPES6 CSLX Components

You will find components in both the top and lower enclosures.


### Top Enclosure



### Power Supplies

The power supplies are located in the top enclosure, along with a power distribution board.


---



- 1) ASSY PCB POWER DISTRIBUTION SV
- 2) POWER SUPPLY 12V 200W Calibrated
- 3) POWER SUPPLY 24V 200W 80-264VAC 47Z
- 4) POWER SUPPLY 48V 200W 80-264VAC 47-63HZ

## Two-Channel Part Tracker Board


The part tracker board is located in the top enclosure.



1) 2-channel Part Tracker - ASSY 2 CHANNEL DPT STACK 5M S6

## Lower Enclosure

These components are located in the lower enclosure, and are referenced in the wiring diagrams.



1) Switch Ethernet 5-Port 10/100/1000T - part number 80926

2) Assembly Driver/ Light Control - part number 66459

## Inspection Module Adjustments


Inspection module adjustments include the camera position, aperture, and camera focus.

The focus adjustment controls the clarity of the image; the aperture adjustment controls the amount of light admitted by the shutter. Normally the inspection modules do not require further adjustment after initial system setup. Circumstances that might require additional adjustments are camera replacement, strobe replacement, or a substantial change in part size or color.

**⚠ Danger** - The inspection modules are mounted near moving machinery. Use extreme caution to avoid contact with moving machinery when servicing inspection modules as serious personal injury could result. Ensure machinery is in an emergency stop state before servicing inspection modules.

## Observe the Part Image

When adjusting the focus, aperture, or height for any inspection module, it is helpful to use Offline Imaging so that you can immediately see the effect of an adjustment on the image quality.



### To use Run in Immediate Mode:

1. Make sure the lane is offline.



2. Right-click a sensor button.
3. Select Offline Imaging from the menu.
4. Click the Run button under Immediate Mode, then run a part through the inspection module.

While the system is in this mode, you will be able to make adjustments to focus, aperture, or camera height.


## Adjust the Camera Position



**WARNING** - Keep clear of reject devices. Projectiles may cause injury.


If you switch to a new type of part that is significantly larger or smaller than the previous part type, you may need to adjust the camera height.

Make sure that the part image is fully in the camera view, but with enough room outside the part for the image to move from part to part.



1. Carefully open the door of the module.
2. Make a note of where the camera currently is. You could use a marker to mark the ruler, or write a note in the part program using the "Edit Notes" feature from Manage Part Programs.
3. Observe the Part Image on the monitor.
4. While holding one camera, unlock the lever to release the camera position. [1] There is one lever for each camera (if applicable).

*Note: your system may have one or two cameras, and the cameras and lenses may look different than shown in this illustration.*



5. Move the camera to the new desired position. Make sure the focus and aperture are still good.
6. If the camera is at its lowest position for your part sizes, move the stop to the position where the camera should stop. [2] This will allow for easy adjustment in the future, to set the lowest camera position. There is one stop for each camera (if applicable for your system).
7. Lock the lever.
8. Repeat for the other camera (if applicable).
9. Close the module cover.

## Lighting Adjustments

To adjust the lighting, use the software adjustments.

### **To see the image on the screen:**

Observe the Part Image

Adjust lighting through either:

- Basic adjust lighting, or
- Advanced adjust lighting

Most often, you will use Basic Adjust Lighting.


## Chapter 6 Wiring Diagrams CPE S6 Inspection Module

The following diagrams are for the main enclosure part number 85954.

# Wiring Diagram CSLX Top Enclosure Sheet 1

## CPES6 MASTER 85954

## POWER PANEL




**ENCLOSURE LABEL**  
SEE PROJECT ENGINEER FOR SYSTEM NUMBER AND PART NUMBER.

**Model: ASSY ENCLOSURE MODULE CPES6 CSLX**

|                                      |                 |
|--------------------------------------|-----------------|
| System Number: XXXXX                 | Volts~: 100-240 |
| Part Number: 85954                   | Watts: 300      |
| Enclosure Type: 1                    | Phase: 1        |
| Year of Construction: 20XX           | Hertz: 50/60    |
| Short Circuit Current Rating (kA): 5 |                 |
| Electrical Diagram: 85954W           |                 |

---

**PRESSCO** Technology, Inc  
29200 Aurora Road  
Solon, Ohio 44139  
440-498-2600  
www.pressco.com



Made in USA

# Wiring Diagram CSLX Top Enclosure Sheet 2


## CPES6 MASTER 85954

DOC. VERSION: 01  
DOCUMENT NO.: 85954W  
PAGE: 2 OF 6


SW1-24V SELECTOR SWITCH:  
SET TO DESIRED POSITION:  
EXT-EXTERNAL 24VDC PS  
CTR-NO VOLTAGE  
XIO-EXTENDED I/O 24VDC

EXTERNAL 24V PS MUST BE CONNECTED TO +VX AND -VX.

NOTE: DO NOT CONNECT EXTERNAL PS TO +VI OR -VI.





MB1-8 PORT I/O






LIGHT TREE (OPTIONAL)

DPT STACK 78523




ETHERNET SWITCH-12VDC  
BLK/12VRET: V1-  
RED/+12VDC: V1+



# Wiring Diagram CSLX Main Enclosure Sheet 3


## CPES6 MASTER 85954 With PD7 Camera



**Wiring Diagram CSLX Main Enclosure Sheet 4**

|                           |  |
|---------------------------|--|
| DOC. VERSION<br><b>01</b> | DOCUMENT NO.<br><b>85954W</b><br>PAGE 4 OF 6 |
|---------------------------|--|


**CPES6 MASTER 85954  
With PD13 Camera**




Wiring Diagram CSLX Main Enclosure Sheet 5

CPES6 MASTER 85954

8-PORT I/O BOX-MB1



8-PIN PANEL CONNECTOR





This page left blank intentionally

## Chapter 7 Maintenance Frequency with Chromapulse Modules

| Item                             | Description   | Frequency |
|----------------------------------|---|-----------|
| Observe proper rejection         | Verify that defective parts are being rejected by inserting a known defective part through inspection | Daily     |
| Observe Proper inspection        | Verify that no stray parts are stuck in or near the inspection module or reject station               | Daily     |
| Observe Proper inspection        | Verify that no buildup of dirt or contaminants has occurred on inspection module. Clean if necessary. | Daily     |
| Observe Proper inspection        | Verify that each camera's image is properly centered, focused, and properly lit. Adjust if necessary. | Daily     |
| Glass surfaces                   | Clean with soft, clean, oil-free cloth dampened with glass cleaning solution                          | Daily     |
| Plastic surfaces                 | Clean with soft, clean, oil-free cloth dampened with mild soap and water solution                     | Daily     |
| Part Detect Sensor and Reflector | Clean with soft, clean, oil-free cloth dampened with mild soap and water solution. Wipe dry.          | Weekly    |
| Support Package                  | Create a snapshot of your Intelispec settings.  | Monthly   |
| Camera lens                      | Clean only with lens tissue and lens cleaner. Be careful not to alter focus or aperture.              | Monthly   |
| Fan filters                      | Rinse in clean water; use mild soap and water solution if oily.                                       | Monthly   |
| Acronis Backup                   | Create a full System Backup.  | Yearly    |

### Maintenance for the Inspection Module



*Important - Debris and contamination could build up on both the glass and plastic surfaces. This dirt could appear in the inspection windows, causing false rejects of parts, or it could degrade lighting. Clean glass and plastic surfaces often to avoid false rejects.*

## Chapter 7

To maintain proper image quality and system performance, the clear glass and plastic surfaces on the Inspection Modules must be cleaned on a regular basis. Dirt and debris that appear in the image can cause false rejects. An oily film on optical surfaces can cause false rejects or missed defects.

## Clean or Replace the CPES6 Fan Filters

Replace the filters once a month, using **part number 55197 - replacement filter element**. These come in a package of five that initially ships with the system. There will be up to four fan/ vent filters, depending on your model number.


### To replace the filters:

These can be accessed from the outside of the module, without opening any doors or panels. The locations are shown below.


1. Pry the filter covers off with your fingers or with a tool such as a plastic screwdriver. Do not use metal tools as they will scratch the paint.
2. If you have a new filter, install the new filter. Then go to step 4.
3. If you do not have replacement filters, clean them once per month.
  - If the filters contain only dry dust and dirt, rinse them in plain water
  - If the filters contain oily dust and dirt, clean them in soapy water
  - Dry the filters completely before reinstalling them
4. Snap the filter covers back in place.

**Note:** Refer to the illustration below for the locations of the fan and vent filters (these are the same filter types).

- 1 and 2) View A is the front side of the module and shows the fan locations (both master and slave modules shown)
- 3 and 4) View B is the back side of the module and shows the vent locations



## Clean the Optical Surfaces

 **Important** - Debris and contamination could build up on both the glass and plastic surfaces. This dirt could appear in the inspection windows, causing false rejects of parts, or it could degrade lighting. Clean glass and plastic surfaces often to avoid false rejects.

To maintain proper image quality and system performance, the clear glass and plastic surfaces on the Inspection Modules must be cleaned on a regular basis. Dirt and debris that appear in the image can cause false rejects. An oily film on optical surfaces can cause false rejects or missed defects.

## Clean the Glass Surfaces

Glass surfaces that may require cleaning are:

- Camera Lens
- Beam Splitter (if present)
- Secondary lens (if present)
- Secondary mirror (if present)


### To clean glass surfaces:

- Blow off dust with canned, compressed air
- Use a clean non-abrasive cloth dampened with lens cleaning solution
- Use lens tissue and lens cleaning solution on camera lenses
- If surface has compound on it, first clean with alcohol, then with lens cleaning solution


*Note: Cleaning frequency will depend on plant and process conditions.*

## Clean the Chromapulse Beam Splitter

If your module has a beam splitter, clean the glass carefully.


 **CAUTION:** To prevent damage to the inspection module, do not remove the beam splitter for cleaning. Clean it while it is still inside the module.

 **CAUTION:** Do not move the position of the glass, or else the part image will not be correct for inspection.

 **CAUTION:** Do not touch lenses with fingers or oily cloths.

### To clean beam splitter:

1. Blow off dust from beam splitter with canned, compressed air.
2. Clean the glass on the beam splitter using lens tissue and lens cleaner.



## Clean the Plastic Surfaces - general

*Note: Cleaning frequency will depend on plant and process conditions.*

### **To clean plastic surfaces:**

- Use canned compressed air to blow away dust
- Use a clean, non-abrasive cloth dampened with mild soap and water solution. Saturate surface completely to let particles wash away.
- Dry the surface with clean, compressed air



*DO NOT: Use paper towels, paper napkins, or dry cloths – these may scratch surfaces*

## Clean the Part Detector without the Reflector

Your system will be equipped with either a part detector or proximity sensor, depending on your application. The proximity sensor does not use a reflector. However, the cleaning procedure for either of these types of sensors is similar.

The part detect sensor and reflector surfaces of the part detector must remain clean to properly detect parts. Clean these surfaces regularly to prevent dirt and oil build-up.

### **To clean the part detector:**

- Clean the part detector surfaces with a soft, clean, lint-free cloth dampened with a mild soap and water solution
- Clean the sensors on both sides of the conveyor
- Do not use a glass cleaning solution or strong solvent on plastic surfaces as they might be damaged.

*Note: the frequency of cleaning will depend on plant and process conditions*

Chapter 7

